


Montage- en gebruikshandleiding - NL

Aluminium Soccer Goal

500x200cm









WARNING
CHOKING HAZARD
small parts



Adult assembly required
retain for future reference



PLAY  MORE

Nummer	Titel		Aantal & onderdeelnummer
1	Buis 1		2
2	Buis 2		2
3	Buis 3		4
4	Buis 4		2
5	Buis 5		6
6	Buis 6		8
7	Buis 7		1
8	Buis 8		1
9	Buis 9		2
10	Buis 10		2
11	Buis 11		2
12	Buis 12		2
13	Gebogen sluitring		96
14	M8 Korte bout		44
15	M8 Lange bout		4
16	M6 bout + moer		24
17	M6 Inbussleutel (L-vorm)		1
18	M8 Inbussleutel (L-vorm)		1
19	Voetbalnet		1
20	Spankoord		1
21	Afstelbuis voor netclips		1
22	U-vormige grondpen		7
23	Elastisch koord (optioneel)		8





HARTELIJK GEFELICITEERD

MET DE KOOP VAN UW PRODUCT!

Lees de gebruiksaanwijzing zorgvuldig door. De gebruiksaanwijzing is een vast bestanddeel van het product. Bewaar de gebruiksaanwijzing en verpakking dus zorgvuldig voor eventuele vragen op een later tijdstip. Wanneer u het product aan derden overdraagt, moet u de gebruiksaanwijzing ook meegeven. Dit product moet door een volwassene gemonteerd worden. Dit product is niet geconstrueerd en niet toegelaten voor commercieel gebruik. Het gebruik van dit product vereist bepaalde vaardigheden en kennis. Gebruik het uitsluitend in overeenstemming met de leeftijd en gebruik het product uitsluitend voor het beoogde doel.

VEILIGHEIDSTIPS

- **WAARSCHUWING!** Dit voetbaldoel is niet geschikt voor kinderen jonger dan 14 jaar. Gebruik uitsluitend onder toezicht van een volwassene.
- Controleer voor elk gebruik alle onderdelen van de goal op beschadiging en correcte montage. Het is daarbij belangrijk om te controleren of de verbindingdelen en schroefverbindingen goed vastzitten. Eventueel ontstane scherpe randen moeten meteen verwijderd worden!
- Waarschuwing: Klim in geen geval op het doelframe of het net en ga ook niet aan de stangen hangen. Dit kan ernstige ongelukken en verwondingen tot gevolg hebben!
- Wanneer het product door kinderen wordt gebruikt, mag dat alleen gebeuren onder toezicht van volwassenen.
- Wij aanvaarden geen aansprakelijkheid voor schade die het gevolg is van het feit dat deze gebruiksaanwijzing niet opgevolgd werd.

MONTAGE-INSTRUCTIES

Aanwijzing: Het product moet door 2 volwassenen opgebouwd worden. Smeer voor de montage een beetje olie op de smalle einden van de insteekverbindingen. Dat vereenvoudigt de montage en verlengt de levensduur van het product!

MONTAGE VAN HET DOELFRAME

(zie afbeelding 1)

Verwijder alle componenten uit de verpakking en leg vooral de genummerde buisdelen alsmede het doelnet gesorteerd klaar. Om te zorgen voor een soepele opbouw, vooral van het omhulsel van het frame, dient u beslist de opbouwvolgorde in acht te nemen.

Stap 1 – Eerst voorframe, daarna steunframe

- Monteer eerst het voorframe: buis 1, 2, 3, 4, 6, 7, 8, 9.
 - Monteer daarna het achterste steunframe: buis 10, 11, 12.
- Let op: Draai bouten pas volledig vast als het hele frame gemonteerd en uitgelijnd is.

Stap 2 – Gebruik de juiste bouten

- Voor buis 10 naar bovenbuizen 1 en 2, en buis 12 naar onderbuizen 1 en 2: gebruik M8 lange bouten met gebogen sluitringen.
- Voor verbindingen met buis 5: gebruik de bevestigingsmaterialen zoals aangegeven in stap 3.
- Voor alle overige verbindingen: gebruik korte bouten met gebogen sluitringen.

Stap 3 – Buis 5 en 6 monteren

Let op: Buis 5 en 6 zijn dunner dan de framebuizen en schuiven in de framebuizen.

1) Zo herken je buis 5 en 6

- **Buis 5:** heeft 4 doorlopende gaten en 2 extra verticale gaten.
- **Buis 6:** heeft alleen 4 doorlopende gaten.

2) Montage

- Schuif één uiteinde van de verbindingsbuis in de eerste framebuis, lijn de gaten uit en zet vast.
- Schuif daarna het andere uiteinde in de volgende framebuis, lijn de gaten uit en zet ook vast.

3) Gebruik de juiste bevestiging

- **Buis 6:** gebruik M8 korte bouten met gebogen sluitringen.
- **Buis 5:**
 - **2 verticale gaten:** gebruik M6 bout + moer en gebogen sluitringen.
 - **2 middelste gaten van de 4 horizontale gaten:** gebruik M6 bout + moer en gebogen sluitringen.
 - **2 buitenste gaten van de 4 horizontale gaten:** gebruik M8 korte bouten met gebogen sluitringen.

Stap 4 – Oriëntatie netclips

- Clip-structuur: Elke netclip heeft drie haken (de middelste haak staat in tegengestelde richting van de twee buitenste)
- Cruciale richting: De openingen van de twee buitenste haken moeten naar de binnenzijde (speelzijde) van het doel wijzen (de dichte rug van deze haken wijst naar buiten)
- Dit zorgt voor een sterke en duurzame bevestiging van het net.

Montage van het voetbalnet

Stap 5 – Net aan het frame bevestigen (netclips)

Het voetbalnet wordt met metalen netclips aan het frame bevestigd. Deze stap beschrijft de juiste manier van bevestigen met netclips.

- Steek het netkoord door de netclip
 - Plaats het koord eerst in de middelste haak
 - Druk het koord daarna stevig in de twee buitenste haken
 - Trek het net recht voordat u verdergaat met de volgende clip
- Herhaal deze werkwijze voor de bevestiging van het net aan het frame.

Stap 6 – Hoofdnet monteren (voorzijde en onderzijde)

Monteer eerst het grote hoofdnet.

- Leg het hoofdnet over het doel
- Bevestig het net aan de horizontale buizen aan de voorzijde, zowel boven als onder (zie afbeelding 2)
- Zorg dat het net gelijkmatig wordt bevestigd en niet verdraaid is

Stap 7 – Net opspannen met spankoord

Omdat het net bij dit formaat dik en zwaar is, moet het eerst worden opgespannen.

- Leid het spankoord door het net
 - Trek het net strak en bevestig het koord aan de achterste staande buizen
 - Span het net gelijkmatig, zodat het netjes strak staat (zie de verdikte lijn in afbeelding 2)
- Dit voorkomt dat het net later doorzakt.

Stap 8 – Zij-netten monteren

Nadat het hoofdnet strak is opgespannen, kunnen de zij-netten worden gemonteerd. Bevestig de zij-netten aan beide zijanten van het doel. Gebruik hiervoor dezelfde netclips. Trek het net telkens recht voordat u de volgende clip bevestigt.

Stap 9 – Netclips afstellen (indien nodig)

Als de netclips te strak zijn en het net moeilijk kan worden geplaatst:

- Gebruik de afstelbuis voor netclips. Buig de clip voorzichtig iets open.
- Bevestig het net opnieuw zoals beschreven in stap 5.

Stap 10 – Extra bescherming bij krachtig spel (optioneel)

- Gebruik: Bevestig een elastisch koord tussen het net en de doelbuis. Werking: Het koord vangt de impact van harde schoten op en helpt voorkomen dat de netclips vervormen

VEILIGE PLAATSING VAN HET DOEL

Fixeer als laatste stap van het doelframe met de haringen aan de grond. Controleer of de grond geschikt is voor het gebruik van haringen (bijv. geen waterleiding voor gazonsproeiers in de grond!). Zorg ervoor dat de haringen helemaal in de grond geslagen zijn en stevig vastzitten. Voorkom uitstekende haken (risico op struikelen). Op een te harde ondergrond moet het doel door geschikte maatregelen anders tegen omvallen beveiligd worden om een risico op lichamelijke schade op het lichamenlijk letsel te vermijden. Speel nooit met een goal die niet vastgezet is en laat hetdoel ook niet los achter.

CONTROLE NA MONTAGE

- Bouten/ringen volledig vast.
- Frame recht en stabiel.
- Net strak; clips correct gericht.

INFORMATIE VOOR GEBRUIK

- Zet het doel uitsluitend op een vlakke ondergrond op.
- Houd een minimale afstand van 3 meter aan tussen het opgebouwde doel en omliggende hindernissen.
- Beveilig het doel altijd tegen omvallen - ook als het niet in gebruik is.
- Stel het product niet onnodig bloot aan slechte weersomstandigheden. Berg het op een droge en koele plek op.
- Let op eventuele roestplekken op het product en werk die meteen bij. Door het in elkaar schuiven van de metalen delen kunnen krassen in de bescherm laag gemaakt worden, waardoor roest kan ontstaan.

AANWIJZING VOOR DE AFVOER AAN HET EINDE VAN DE LEVENSDUUR


Laat het toestel aan het einde van de levensduur afvoeren via de ter beschikking staande teruggave- en inzamelsystemen. Met eventuele vragen kunt u terecht bij afvalverwerkers bij u in de buurt.



Assembly instructions - EN

Aluminium Soccer Goal






500x200cm






WARNING
CHOKING HAZARD
small parts

Adult assembly required
retain for future reference



Number	Part name	Image	Quantity
1	Tube 1		2
2	Tube 2		2
3	Tube 3		4
4	Tube 4		2
5	Tube 5		6
6	Tube 6		8
7	Tube 7		1
8	Tube 8		1
9	Tube 9		2
10	Tube 10		2
11	Tube 11		2
12	Tube 12		2
13	Curved Washer		96
14	M8 Short bolt		44
15	M8 Long bolt		4
16	M6 Connecting bolt and barrel nut		24
17	M6 L-shaped hex wrench		1
18	M8 L-shaped hex wrench		1
19	Net for soccer goal		1
20	Tension cord		1
21	Adjustment tube for net clips		1
22	Ground peg		7
23	Elastic cord (optional)		8





CONGRATULATIONS

ON THE PURCHASE OF YOUR PRODUCT!

Please read the instructions carefully. The instructions are an important part of the product. Please properly keep the instructions and the packaging for future reference if you have any questions. When you transfer this product to someone else, you must also provide the instructions. This product must be installed by adults. This product has not been designed and is not allowed for commercial use. Using this product requires certain safety knowledge and skills. Please use this product strictly within the applicable age range and only for the intended purpose.

SAFETY TIPS

- **WARNING!** This football goal is not suitable for children under 14 years of age. Use only under adult supervision.
- Before each use, check all parts of the goal for damage and correct assembly. In particular, make sure that all connectors and screw fittings are securely tightened. Any sharp edges that may have formed must be removed immediately.
- **WARNING:** Do not climb on the goal frame or the net, and do not hang from the bars under any circumstances. This may result in serious accidents and injuries.
- When children use this product, it must be under adult supervision at all times.
- We accept no liability for damage resulting from failure to follow these instructions.

ASSEMBLY STEPS

Note: The product must be assembled by two adults. Before assembly, apply a small amount of oil to the narrow ends of the push-fit connectors. This makes assembly easier and helps extend the product's service life!

ASSEMBLY OF THE GOAL FRAME

(see Figure 1)

Remove all components from the packaging and lay them out, especially the numbered tube sections and the goal net, in an organised manner. To ensure smooth assembly—particularly of the frame cover—be sure to follow the assembly sequence.

Step 1 – Assemble the front frame first, then the support frame

- First assemble the front frame: Tubes 1, 2, 3, 4, 6, 7, 8 and 9.
 - Then assemble the rear support frame: Tubes 10, 11 and 12.
- Note: Do not fully tighten the bolts until the entire frame has been assembled and properly aligned.

Step 2 – Bolt types for the frame connections

- **Tube 10 to upper Tubes 1 and 2, and Tube 12 to lower Tubes 1 and 2:** use M8 long bolts with curved washers.
- **Connections involving Tube 5:** use the fixings specified in Step 3.
- **All other connections:** use short bolts with curved washers.

Step 3 – Connecting tubes 5 and 6

Note: Tubes 5 and 6 are thinner and fit inside the frame tubes.

1) Identify Tube 5 and Tube 6

- Tube 5: has 4 through-holes and 2 additional vertical through-holes.
- Tube 6: has 4 through-holes only (no vertical holes).

2) Fit the connecting tube

- Insert one end of the connecting tube into the first frame tube, align the holes, and secure it.
- Then insert the other end into the next frame tube, align the holes, and secure it.

3) Use the correct fixings

- **Tube 6:** use M8 short bolts with curved washers.
- **Tube 5:**
 - **Vertical 2 holes:** use M6 connecting bolts and barrel nuts with curved washers.
 - **Centre holes of the horizontal 4 holes:** use M6 connecting bolts and barrel nuts with curved washers.
 - **Outer holes of the horizontal 4 holes:** use M8 short bolts with curved washers.

Step 4 – Net clip orientation

- Clip design: Each net clip has three hooks. The centre hook faces the opposite direction to the two outer hooks.
 - **Correct orientation (important):** The openings of the two outer hooks must face towards the inside of the goal (the playing side). The solid “back” of these hooks faces outwards.
- This ensures a strong and durable attachment of the net.

ATTACHING THE SOCCER GOAL NET

Step 5 – Securing the net to the frame (net clips)

The football net is attached to the frame using metal net clips. This step explains the correct method for securing the net with the net clips.

- Thread the net cord through the net clip.
 - First, place the cord into the centre hook.
 - Then press the cord firmly into the two outer hooks.
 - Pull the net straight before moving on to the next clip.
- Repeat this procedure to attach the net to the frame.

Step 6 – Fitting the main net (front and bottom)

Fit the large main net first.

- Place the main net over the goal.
- Attach the net to the horizontal tubes at the front, both at the top and the bottom (see Figure 2).
- Make sure the net is attached evenly and is not twisted.

Step 7 – Tensioning the net with the tension cord

As the net for this size is thick and heavy, it must first be tensioned.

- Thread the tension cord through the net.
 - Pull the net tight and fasten the cord to the rear upright tubes.
 - Tension the net evenly so that it sits neatly and firmly in place (see the bold line in Figure 2).
- This helps prevent the net from sagging over time.

Step 8 – Fitting the side nets

Once the main net has been properly tensioned, the side nets can be fitted.

- Attach the side nets to both sides of the goal.
- Use the same net clips for this step.
- Pull the net straight each time before securing the next clip.

Step 9 – Adjusting the net clips (if required)

If the net clips are too tight and the net is difficult to fit:

- Use the adjustment tube for the net clips.
- Carefully open the clip slightly.
- Reattach the net as described in Step 5.

Step 10 – Extra protection for powerful play (optional)

Use: Attach an elastic cord between the net and the goal tube.

- How it works: The cord absorbs the impact of powerful shots and helps prevent the net clips from becoming deformed.

SAFE POSITIONING OF THE GOAL

As the final step, secure the goal frame to the ground using the ground pegs. Check that the ground is suitable for using pegs (e.g. ensure there are no underground irrigation or water pipes). Make sure the pegs are driven fully into the ground and are firmly secured. Avoid any protruding hooks (risk of tripping).

On very hard surfaces, the goal must be secured against tipping over by other suitable means to prevent the risk of injury. Never play with a goal that is not secured, and do not leave the goal unsecured and unattended.

CHECK AFTER ASSEMBLY

- Tighten all bolts and washers fully.
- Ensure the frame is straight and stable.
- Ensure the net is taut and the clips are correctly oriented.

INFORMATION FOR USE

- Set up the goal on a level surface only.
- Keep a minimum distance of 3 metres between the assembled goal and any surrounding obstacles.
- Always secure the goal against tipping over, even when it is not in use.
- Do not expose the product unnecessarily to adverse weather conditions. Store it in a cool, dry place.
- Check the product for any signs of rust and treat them immediately. Sliding the metal parts together may scratch the protective coating, which can cause rust to develop.

DISPOSAL AT END OF SERVICE LIFE

At the end of its service life, dispose of the product via the available return and collection systems. If you have any questions, please contact your local waste disposal or recycling services.

