

FARPOINT / FAIRVIEW SERIES



FARPOINT 80



FARPOINT 70



FARPOINT 55



FARPOINT 40



FAIRVIEW 70



FAIRVIEW 55



FAIRVIEW 40

Welcome to Osprey. We pride ourselves on creating the most functional, durable and innovative carrying product for your adventures. Please refer to this owner's manual for information on product features, use, maintenance, customer service and warranty.

OWNER'S MANUAL



ospreyeurope.com

OVERVIEW



SHARED FEATURES

- 1 Large panel lockable zip access to main compartment
 - 2 Dual front compression straps
 - 3 Dual front mesh pockets
 - 4 Padded top and side handles
 - 5 Zippered rear flap to stow and protect hipbelt and harness
 - 6 Stowaway backpanel, harness and hipbelt with zippered rear flap for protection
- + Two internal compression straps hold contents securely
 - + Internal front flap zippered mesh pocket

FABRIC

MAIN	210D Nylon Mini Hex Diamond Ripstop
ACCENT	600D Packcloth
BOTTOM	600D Packcloth

OVERVIEW



FARPOINT 80

MEN'S

SPECS	S/M	M/L
Cubic Inches	4637	4882
Liters	76	80
Pounds	3.73	3.88
Kilograms	1.69	1.76
Inches	29h x 15w x 16d	
Centimeters	74h x 38w x 40d	
LOAD RANGE	20-50 lb 9-23 kg	



UNIQUE FEATURES

- 1 Large lower zippered compartment with floating divider
- 2 Top zippered liquids pocket
- 3 Zippered front panel slash pocket
- 4 External gear attachment points
- 5 Daylite attachment loops

FARPOINT 70

MEN'S

SPECS	S/M	M/L
Cubic Inches	4089	4272
Liters	67	70
Pounds	3.75	3.92
Kilograms	1.71	1.78
Inches	26h x 13w x 13d	
Centimeters	65h x 33w x 34d	
LOAD RANGE	20-50 lb 9-23 kg	



UNIQUE FEATURES

- 1 Removable sleeping pad straps
 - 2 Zip-off daypack with lockable zip main compartment
- + Stowaway reverse spacermesh harness
 - + Laptop and tablet sleeve
 - + Heat-embossed, scratch-free zippered slash pocket

OVERVIEW



FARPOINT 55

MEN'S

SPECS	S/M	M/L
Cubic Inches	3173	3356
Liters	52	55
Pounds	3.75	3.92
Kilograms	1.69	1.76
Inches	25h x 13w x 13d	
Centimeters	65h x 32w x 32d	
LOAD RANGE	20-50 lb 9-23 kg	



UNIQUE FEATURES

- 1 Removable sleeping pad straps
 - 2 Zip-off daypack with lockable zip main compartment
- + Stowaway reverse spacermesh harness
 - + Laptop and tablet sleeve
 - + Heat-embossed, scratch-free zippered slash pocket

FARPOINT 40

MEN'S

SPECS	S/M	M/L
Cubic Inches	2319	2441
Liters	38	40
Pounds	3.11	3.17
Kilograms	1.41	1.44
Inches	21h x 14w x 9d	
Centimeters	54h x 35w x 23d	
LOAD RANGE	20-40 lb 9-18 kg	



UNIQUE FEATURES

- 1 Laptop and tablet sleeve
- 2 Heat-embossed, scratch-free zippered slash pocket
- 3 Shoulder strap included

OVERVIEW



FAIRVIEW 70

WOMEN'S

SPECS	WXS/M	WS/M
Cubic Inches	4089	4272
Liters	67	70
Pounds	3.78	3.87
Kilograms	1.71	1.76
Inches	25h x 14w x 12d	
Centimeters	64h x 35w x 31d	

LOAD RANGE 20-50 lb | 9-23 kg



UNIQUE FEATURES

- 1 Removable sleeping pad straps
 - 2 Zip-off daypack with lockable zip main compartment
- + Stowaway reverse spacermesh harness
 - + Laptop and tablet sleeve
 - + Heat-embossed, scratch-free zippered slash pocket

FAIRVIEW 55

WOMEN'S

SPECS	WXS/M	WS/M
Cubic Inches	3173	3356
Liters	52	55
Pounds	3.07	3.20
Kilograms	1.71	1.75
Inches	25h x 13w x 12d	
Centimeters	63h x 33w x 30d	

LOAD RANGE 20-50 lb | 9-23 kg



UNIQUE FEATURES

- 1 Removable sleeping pad straps
 - 2 Zip-off daypack with lockable zip main compartment
- + Stowaway reverse spacermesh harness
 - + Laptop and tablet sleeve
 - + Heat-embossed, scratch-free zippered slash pocket

FAIRVIEW 40

WOMEN'S

SPECS	WXS/M	WS/M
Cubic Inches	2319	2441
Liters	38	40
Pounds	3.09	3.16
Kilograms	1.40	1.44
Inches	21h x 14w x 9d	
Centimeters	54h x 35w x 23d	

Load Range 20-40 lb | 9-18 kg



UNIQUE FEATURES

- 1 Laptop and tablet sleeve
- 2 Heat-embossed, scratch-free zippered slash pocket
- 3 Shoulder strap included

1 LIGHTWIRE™ FRAME SUSPENSION

- + 3.5 mm LightWire™ peripheral frame effectively transfers load from harness to hipbelt
- + Atilon framesheet spreads load across entire back-panel to peripheral frame
- + Adjustable load lifters transfer weight from harness to hipbelt

2 STOWAWAY REVERSE SPACERMESH BACKPANEL, HARNESS, HIPBELT

- + Smooth, mesh-covered Atilon foam provides comfortable, breathable contact surface with load-supporting core



SIZING / FIT

FARPOINT - MEN'S SIZING

S/M	15-19" / 38-48 cm
M/L	18-22" / 46-56 cm

FAIRVIEW - WOMEN'S SIZING

WXS/S	13-17" / 33-43 cm
WS/M	16-20" / 41-51 cm

WOMEN'S SPECIFIC FIT

PACK'S SHAPE

Lowering the pack's center of gravity and creating a narrower pack profile with added depth in the right places and allows greater freedom of movement with increased stability, as well as increased comfort and load support.

HARNESS

Angled and shaped shoulder harness straps with varying padding thicknesses accommodate anatomical differences in the neck, shoulders, chest and creates an optimal fit and better distributed loads to ensure comfort. It is important to adjust the sternum strap for proper harness fit.

HIPBELT

Women's hips tend to be more conically shaped and require uniquely angled hipbelts with varying padding thickness and narrowed heights to provide proper anatomical fit and avoid uncomfortable pressure in the upper thighs or ribs. We sculpt and angle our hipbelts thoughtfully for proper load transfer and support.



HARNESS FIT

The harness straps should wrap fully around your shoulders with no gaps between the pack and your back. The padded part of the harness straps should end 1 1/2 cm - 2 1/5 cm below the armpits and the sternum strap adjusted to approximately 2 1/5 cm below the collarbone.

FEATURE DETAILS



FARPOINT / FAIRVIEW DAYPACK*

70L / 55L

Farpoint Daypack conveniently attaches to the main harness of the Farpoint pack to provide easy access to gear essentials.

SPECS	O/S
Cubic Inches	915
Liters	15
Pounds	1.12
Kilograms	0.51
Inches	17h x 11w x 9d
Centimeters	42h x 27w x 22d

To remove Farpoint Daypack from main Farpoint body:

- A To remove Daypack, unbuckle the dual front compression straps from the loops on the front panel of the Daypack.
- B Unbuckle the zipper pull that connects the Daypack to the Farpoint body.
- C Unzip the perimeter of the Daypack and pull it away from Farpoint body.
- D Reverse the process to reattach Daypack to Farpoint body.

**Not available on Farpoint 80 or 40*



FARPOINT / FAIRVIEW DAYPACK CARRY*

70L / 55L

To attach Farpoint Daypack to main harness of the Farpoint for front carry:

- A Unzip the rear flap to gain access to the harness and hipbelt.
- B Tuck the flap into the space under the center of the hipbelt and use the hook and loop closure to secure it away.
- C Put the primary Farpoint pack on, buckle and tighten the hipbelt across your hipbones, then tighten the shoulder straps by pulling them down and back.
- D Locate the two male buckles sewn into the top harness of the Farpoint Daypack.
- E Clip each of these to corresponding female buckles on the top of the shoulder straps of the main harness.
- F Reverse the steps to remove the Farpoint Daypack from the Farpoint main pack.

**Not available on Farpoint 80 or 40*

FEATURE DETAILS



LAPTOP AND TABLET SLEEVES

70L / 55L LAPTOP SLEEVE*

Max 15"
Inches 13h x 10.5w x 1.5d
Centimeters 33h x 27w x 3.755d

70L / 55L TABLET SLEEVE*

Inches 9.5h x 9w x 1d
Centimeters 24h x 23w x 2d

40L LAPTOP SLEEVE**

Inches 14h x 11w x 1.5d
Centimeters 36h x 28w x 3.755d

40L TABLET SLEEVE**

Inches 10.5h x 10.5w x 1d
Centimeters 27h x 27w x 2d

*Featured on Daypack

**Featured on primary pack



LOCKABLE SLIDERS ON MAIN COMPARTMENT ZIPPER

80L / 70L / 55L / 40L

Lockable zippers on the main compartment help secure your pack's contents. We recommend a TSA-recognized lock.



STOWAWAY BACKPANEL, HARNESS AND HIPBELT

80L / 70L / 55L / 40L

To access the backpanel, unzip the rear flap. Tuck the flap into the space under the center of the hipbelt and use the hook and loop closure to secure it away.

- A Unzip the rear flap.
- B Pull out the harness and hipbelt.
- C Tuck the flap into the space under the center of the hipbelt and use the hook and loop closure to secure it away.
- D Reverse the steps to stowaway the backpanel.



DUAL FRONT COMPRESSION STRAPS

80L / 70L / 55L / 40L

Dual front compression straps secure loads and add stability to the pack when not fully loaded.

- A When the pack is full, tighten the front compression straps attached to the buckles at the front edges of the side wall to secure the load.
- B When your pack is less than full, additional tension will keep the load stable.

PACK / RESERVOIR MAINTENANCE



Your Osprey pack is an extremely durable product and is built for years of use. However, some basic pack maintenance will help ensure your pack lasts a lifetime.

OSPREY PACKS

STANDARD MAINTENANCE

- + After each trip be sure to clean out your pack thoroughly.
- + Clean the zippers regularly using mild soap, warm water and soft brush. This will help keep them in proper working condition.
- + If your pack is wet, hang it to dry out of direct sunlight.
- + Loosen all the straps.
- + Wash your pack if dirt, sweat, salt and stains have worked their way into fabrics, webbing or mesh.
[Do not immerse travel packs in water with our HighRoad™ Wheeled Chassis.]

WASHING YOUR PACK

- A Empty the pack including any food, dirt or spilled contents.
- B If your pack has a removable harness and hipbelt, remove them from the pack body.
- C Do NOT wash your pack in a washing machine. Clean your pack and components in a bathtub or large sink using a mild detergent and warm water.
- D Agitate the pack gently. Scrub the inside and outside of all compartments including the pockets with a soft brush.
- E Clean the zippers using a mild soap, warm water and a soft brush. Flush water and soap through the buckles. Keeping dirt and debris out of the zippers and buckles will help keep them in proper working condition.
- F Drain the dirty water from the bathtub or sink and refill with cool clean non-soapy water. Rinse the pack thoroughly. Repeat this step as necessary.
- G Hang your pack to dry outside or in a well ventilated area, out of direct sunlight.

WHEELED TRAVEL LUGGAGE

[Do not immerse travel packs in water with our HighRoad™ Wheeled Chassis.]

- A After each trip, empty the pack including any food, dirt or spilled contents.
- B Clean the zippers regularly using mild soap, warm water and soft brush. This will help keep them in proper working condition.
- C Wipe the exterior of the chassis with a damp cloth or sponge.
- D Clean the pack fabric by scrubbing stains and dirt with warm water, mild detergent and a soft brush or sponge.
- E Use a wet towel with clean non-soapy water to wipe away any soap residue on the pack.
- F Hang your pack to dry outside or in a well ventilated area, out of direct sunlight.

RECOMMENDED CLEANING PRODUCTS

Osprey recommends Nikwax® products for pack care. Be sure to read label directions carefully before applying any product to your pack.

Tech Wash® - Use this with warm water for washing and cleaning your packs or luggage.

Tent & Gear Solar Proof® - Use this spray-on product to protect your packs from UV exposure and to improve water repellency.



For complete instructions on cleaning your Osprey pack, visit: ospreypacks.com/PackTech/PackCare.

OSPREY RESERVOIRS

RESERVOIR STANDARD MAINTENANCE

- + Rinsing out your reservoir after each use should keep your reservoir fresh, especially when using sugary drink mixes.
- + Periodically use Osprey's Hydraulics™ Cleaning Tablets to clean your reservoir.
- + Iodine or other purifying tablets used in your reservoir will not affect the quality of your reservoir. However these tablets may stain the reservoir over time.
- + Freezing your reservoir will not effect the quality of the reservoir. However if the reservoir is filled with water, be aware that water expands when it freezes and can damage your reservoir if it is overfilled.
- + Do NOT pour boiling water into the reservoir. This can damage the reservoir and will void your warranty.
- + Watch "Cleaning an Osprey Hydraulics™ Reservoir" video on Osprey Packs YouTube® page.

CLEANING YOUR RESERVOIR (WITH OSPREY HYDRAULICS™ CLEANING TABLETS)

- A Fill reservoir with warm water. Do not use bleach or boiling water.
- B Add one cleaning tablet to reservoir and close the cap.
- C Let tablet dissolve for 5 minutes with the reservoir laying on its back.
- D Shake the reservoir for 30 seconds to mix and spread the solution.
- E Pinch the bite valve and squeeze the reservoir to remove air and fill the reservoir hose and bite valve with solution.
- F Let the reservoir sit for 15 minutes and then pour out solution.
- G Rinse the reservoir and tube with clean cool water.
- H Hang your reservoir to dry in a well ventilated area.

DEEP CLEANING YOUR RESERVOIR (WITH OSPREY HYDRAULICS™ CLEANING KIT)

- 1 Rinse out the reservoir and fill it with warm water and a mild dish detergent. Do not use bleach or boiling water.
- 2 With the large cleaning brush from Osprey's Hydraulics™ Cleaning Kit scrub the interior of the reservoir.
- 3 Remove the hose from the reservoir and the bite valve from the hose and use the small brush from Osprey's Hydraulics™ Cleaning Kit to scrub the interior of the hose.
- 4 Remove the silicone bite valve cover and clean it and the bite valve with warm soapy water.
- 5 Rinse the interior and exterior of the reservoir, hose and bite valve parts with cool clean water.
- 6 Let the hose and bite valve dry in a well-ventilated area.
- 7 Insert Osprey's Hydraulics™ Cleaning Kit drying rack into the reservoir and hang to dry in a well ventilated area.

For complete instructions on cleaning your Osprey reservoir watch, "Cleaning an Osprey Hydraulics™ Reservoir" at youtube.com/ospreypacks.

For more information on this product and others, pack care, how to pack your pack, our lifetime guarantee, or to contact Osprey Customer Service, visit **ospreyeurope.com**.

OWNER'S MANUAL

